TECH GUIDE

GEORGE MASON UNIVERSITY

Touch Panel

① Blank Screens

Shutdown

② Volume

③ PC
④ Laptop
⑤ Wireless
⑥ Doc Cam

▲ ▼ 🔊 Mute

1:51 PM
8/4/25

Start System - press anywhere on the touch panel

Presentation Controls

① **Blank Screens** — Turn off all displays (press again to restore) while the PC remains on

② **Volume** — Adjust or mute program audio

Display Source Controls

③ **Computer Source** — Show display from the classroom PC. This PC is installed with conferencing apps and annotation software

④ **Laptop Source** — Select to display laptop from a connected laptop (HDMI and USB cables on or under table)

⑤ **Wireless** — Present wirelessly from anywhere in the room using any tablet, mobile device, or laptop. See separate guide for detailed connection instructions

⑥ **Document Camera** — Display documents or objects for in-class or online participants

🔌 Press Shutdown ⟶ Confirm YES to power off audio/video

Classroom Features

Software
- PC is installed with Ink2go for annotating and recording classes and ZOOM for conferencing and remote participation

Wireless Sharing
- Share your device screen wirelessly from a tablet or mobile device by selecting "Wireless" on the touch panel.

Document Camera
- Display or annotate physical documents by placing them under the document camera

Computer Mounted Camera
- Webcam mounted on the monitor is designed to capture the instructor's image and voice when at the teaching console.

Troubleshooting Tips

Can't connect to wireless sharing
- Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password

No Audio in Zoom/Teams
- Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"

No Sound from connected laptop
- Set device audio output to "Crestron"

Can't see Doc Cam in Zoom/Teams
- Set the camera within the software to the document camera. Then share your screen within the software

Scan this QR code to see more details about classroom features and resources