



Classroom Features

- Software**
PC is installed with ZOOM for conferencing and remote participation
- Document Camera**
Display or annotate physical documents by placing them under the document camera
- Microphones**
Use the microphones to project your voice throughout the room
- HDMI Connections**
Connect your own laptop with built in HDMI cables.

Troubleshooting Tips

- Can't connect to wi-fi**
Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- No Audio in Zoom/Teams**
Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"
- No Sound from connected laptop**
Set device audio output device to "Crestron"
- Can't see Doc Cam in Zoom/Teams**
Set the camera within the software to the document camera. Then share your screen within the software

Start System - press anywhere on the touch panel

Presentation Controls

1 Blank Screens

Turn off all displays (press again to restore) while the PC remains on

2 Volume

Adjust or mute program audio

3 Microphone

Adjust or mute the volume of each microphone

4 Computer Source

Show display from the classroom PC. This PC is installed with conferencing apps and annotation software

5 Laptop Source

Select to display laptop from a connected laptop (HDMI and USB cables on or under table)

6 Document Camera

Display documents or objects for in-class or online participants



Press Shutdown → Confirm YES to power off audio/video



Scan this QR code to see more details about classroom features and resources

