



## Start System - press anywhere on the touch panel

- 1 Presentation** **Mode 1:** Show your selected source on all displays
- 2 Group** **Mode 2:** Send each groups content to the nearest display or mirror one group to all displays
- 3 Blank Screens** Turn off all displays (press again to restore) while the PC remains on
- 4 Microphones** Mute/unmute and adjust volume for each microphone
- 5 Computer Source** Show display from the classroom PC or from your personal laptop (use HDMI cable on lectern)
- 6 Volume** Adjust or mute program audio
- 7 Camera Controls** Adjust camera (tilt, pan, zoom) and enable/disable tracking
- 8 Wireless** Flexibly present content from laptop or tablet from anywhere in the room
- 9 Document Camera** Display documents or objects for in-room or online participants
- 10 Camera Tracking** Indicates the status of camera tracking (enabled by default)

Press Shutdown → Confirm YES to power off audio/video

## Classroom Features

- Software**
  - PC is installed with Ink2go for annotating and recording classes and ZOOM for conferencing and remote participation
- Wireless Sharing**
  - Share your device screen wirelessly from an iPad, phone, or computer by selecting "Wireless" on the touch panel.
- Document Camera**
  - Display or annotate physical documents by placing them under the document camera.
- Microphones for In-Room use**
  - Use the lapel, handheld, catchbox, or lectern microphone for better speech in the room
- Microphones for Online use**
  - Ceiling mounted microphones capture your voice for Zoom/Teams sessions.
- Tracking Cameras**
  - Cameras follow your movement automatically and can be adjusted manually from the touch panel.
- Assisted Listening**
  - Support Students with hearing needs. Please see the support office for device checkout

## Troubleshooting Tips

- Can't connect to wireless sharing**
  - Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- No Audio in Zoom/Teams**
  - Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"
- No Sound from connected laptop**
  - Set device audio output to "Crestron"
- Personal wireless mic doesn't work**
  - This system does not support personal mics, contact support staff for assistance
- Can't see Doc Cam in Zoom/Teams**
  - Set the camera within the software to the document camera then share your screen
- Can't see in room cameras on connected laptop**
  - Use the in room computer to use the in room cameras or microphones in Zoom/Teams



Scan this QR code to see more details about classroom features and resources

