

Start System - press anywhere on the touch panel

Display Instructions

- 1 Blank Screens** Temporarily turn off all displays (press again to restore)
- 2 Display choice** First, Select which display you would like to change the display source
- 3 Display Source** Then, Select which source you would like to send to the selected display. Select from the in room PC, connected laptop, document camera, or wireless screen sharing

Sound and Camera Instructions

- 4 Microphones** Mute/unmute and adjust volume for each microphones
- 5 Camera Controls** Adjust view, zoom, pan, and enable/disable tracking
- 6 Volume** Adjust or mute program audio
- 7 Camera Tracking** Adjust camera (tilt, pan, zoom) and enable/disable tracking

Press Shutdown → Confirm YES to power off audio/video

Scan this QR code to see more details about classroom features and resources



1 Blank Screens Shutdown

4 Microphones Volume **6**

Select a display

2

Left

3

Then select a source

PC Main PC Extended Doc Cam

Camera Control

2:15 PM 8/26/25

Laptop Wireless

Mute **7** Camera Tracking is On

Classroom Features

Conferencing Software

- Zoom is installed on the room PC for starting or joining meetings. Access Microsoft Teams through a web browser.

Wireless Sharing

- Share your device screen wirelessly from a tablet or mobile device by selecting "Wireless" on the touch panel.

Document Camera

- Display or annotate physical documents by placing them under the document camera and selecting "Doc Cam"

Microphones for In-Room use

- Use the lapel, handheld or lectern microphone for better speech in the room

Microphones for Online use

- Ceiling mounted microphones capture your voice for Zoom/Teams meetings.

Tracking Cameras

- Cameras follow your movement by default, tracking settings can be adjusted in the camera control menu.

Troubleshooting Tips

Can't connect to wireless sharing

- Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password

No Audio in Zoom/Teams

- Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"

No Sound from connected laptop

- Set device audio output to "Crestron"

Personal wireless mic doesn't work

- This system does not support personal mics; Contact support for assistance

Can't see Doc Cam in Zoom/Teams

- Set the camera within the software to the document camera, then share your screen

Can't see in room cameras on connected laptop

- Use the in room computer to use the in room cameras or microphones in Zoom/Teams