


START HERE: ROOM CONFIGURATION


Room/Camera Configuration: Touch the control panel in the control to wake the system. Choose the desired room and camera layouts to match the current furniture layout



- Room Configuration:** Select the appropriate camera layout from this column. After selecting this option camera tracking will be enabled
- Camera Configuration:** Select the appropriate camera layout from this column. After selecting this option camera tracking will be enabled
- Sound Configuration:** Use these two choices to select which audio source will be routed to the in room speakers.

ROUTING MODE


Routing Mode: After completing the room setup you will be brought to the routing page, use this page to select which source will be displayed on which display



- Destinations:** These are the available destinations that video can be sent to depending on the video wall settings
- Sources:** Here you can see a list of all available sources that can be assigned to the destinations above, includes all HDMI connections around the multi-purpose rooms, Wireless sharing, live camera feeds, or Control room PCs
- How to assign sources:** First, select the desired source from the list of sources. When selected the source will be highlighted with a white border. Then, Select a destination from the list to assign the selected source to the video wall section.

AUDIO CONTROLS

Audio Controls: Use the up and down buttons to raise or lower the volume and the mute button to mute. Press the privacy button on at the top left to mute all microphones.



CAMERA CONTROLS



Camera Controls: Use this menu to control the pan, tilt and zoom of each of the cameras throughout the Global Connections Studio. Press and hold one of the 3 preset buttons to save the current settings, then press it again to recall those settings

MEDIA PRESS FEED PANEL




Press feeds are available in room 1323 for the press to connect their recording or streaming devices. All male XLR jacks on the panel output the same audio as the presentation system from the system

VIDEO WALL CONTROLS

Video Wall Controls: Choose how the multiple display destinations will be arranged on the Video Wall using the buttons on the left. Send a source to a destination by highlighting the source and touching the destination quadrant

- Single full screen:** 1 source centered in a 16x9 window
- Single Wide Screen:** 1 source Stretched to fill the Video Wall
- Side By Side:** 2 sources next to each other
- 4 Sources:** up to 4 sources, displayed in each in a corner
- 8 Sources:** up to 8 sources, displayed in each in a corner
- “Event”(cycle):** More custom layouts available



Scan this QR code to see more details about classroom features and resources

