


Start System - press anywhere on the touch-panel



- 1 Blank Screens** Temporarily turn off all displays (press again to restore)
- 2 Microphone Controls** Adjust the volume of the in room microphones
- 3 Volume** Adjust or mute program audio
- 4 Camera Controls** Adjust view, zoom, pan, and enable/disable tracking
- 5 Display Controls** Use the different columns to control each of the rooms displays independently from each other
- 6 Laptop 1/2/3** Mirror the display of a connected laptop on the display. 3 HDMI connections located on the lectern
- 7 Wireless** Present wirelessly from anywhere in the room using any tablet, mobile device, or laptop. See separate guide for detailed connection instructions

Classroom Features

- **Wireless Sharing**
Share your device screen wirelessly from an tablet or mobile device by selecting "Wireless" on the touch-panel.
- **Microphones for Online use**
Ceiling mounted microphones are designed to capture sound from the entire room
- **3 High Definition Cameras**
3 Cameras above each display capture video for conferencing purposes. Zoom, Tilt, and Pan can be adjusted on the touch-panel
- **3 USB and HDMI connections**
Each display in the room has HDMI and USB ports corresponding to it. Using the touche panel the display from any connection can be displayed on any screen

Troubleshooting Tips

- **Can't connect to wireless sharing**
Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- **Audio video issues in Teams/Zoom**
Ensure the USB and HDMI cables are connected then set speaker and microphone settings within the conferencing software to "AV Bridge"
- **No Sound from connected laptop**
Set Windows or Mac audio output device to "Crestron"
- **No Display from connected laptop**
Ensure your laptop is connected to the corresponding HDMI port that is selected on the touch-panel
- **Can't access cameras or microphones on laptop**
Make sure the UBS cable is connected and the indicator lights at the wall port are on

 Press Shutdown → Confirm YES to power off audio/video



Scan this QR code to see more details about classroom features and resources

