



Start System - press anywhere on the touch-panel

- 1 Blank Screens** Turn off all displays (press again to restore) while the PC remains on
- 2 Microphone Controls** Adjust the volume of the in room microphones
- 3 Volume** Adjust or mute program audio
- 4 Camera Controls** Adjust view, zoom, pan, and enable/disable tracking
There are 7 HDMI panels located around the room. Selecting Laptop 1 through seven will mirror the display and audio to the corresponding HDMI connection. (Default: Laptop 1)
- 5 Laptop Connections** Flexibly share wirelessly from anywhere in the room using any Tablet, mobile device, or laptop. See separate guide for detailed connection instructions
- 6 Wireless** Display the rooms built in PC. This PC can be controlled with a remote located in the room
- 7 Rack PC**

Press Shutdown → Confirm YES to power off audio/video

Classroom Features

- 7 HDMI Connection points**
This room features 7 HDMI inputs located around the room for participants to connect to in order to share content
- Wireless Sharing**
Share your device screen wirelessly from an tablet or mobile device by selecting "Wireless" on the touch-panel.
- Ready for VR**
Power, WiFi and Data connections ready for use with VR technology. See your department support office for available devices
- Microphones for Online use**
A large hanging microphone serves to capture audio from participants and can be used for conferencing and remote participation
- Tracking Cameras**
Cameras follow your movement by default, tracking settings can be adjusted in the camera control menu.

Troubleshooting Tips

- Can't connect to wireless sharing**
Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- No Audio in Zoom/Teams**
Set speaker and microphone settings within the conferencing software to "AV Bridge"
- No Sound from connected laptop**
Set Windows or Mac audio output device to "Crestron"
- No Display from laptop**
Ensure the touch-panel source is set to the corresponding HDMI input that the desired laptop is connected to.
- Can't see in room cameras on connected laptop**
Use the in room computer to use the in room cameras or microphones in Zoom/Teams



Scan this QR code to see more details about classroom features and resources

