



Horizon Hall 1300

November 19, 2025 10:49 AM

Help

Start System - press anywhere on the touch panel

- 1 Computer Source** Show display from the classroom PC or from your personal laptop (use HDMI cable on lectern)
- 2 Wireless** Flexibly present content from laptop or tablet from anywhere in the room
- 3 Document Camera** Display documents or objects for in-room or online participants
- 4 Blank Screens** Turn off all displays (press again to restore) while the PC remains on
- 5 Volume** Adjust or mute program audio
- 6 Camera Controls** Adjust camera (tilt, pan, zoom) and enable/disable tracking
- 7 Camera Tracking** Indicates the status of camera tracking (enabled by default)
- 8 Screens** Raise or lower the projection screen to access the white boards behind

Classroom Features

- Software**
 PC is installed with Ink2go for annotating and recording classes and ZOOM for conferencing and remote participation
- Wireless Sharing**
 Share your device screen wirelessly from an tablet or mobile device by selecting "Wireless" on the touch panel.
- Document Camera**
 Display or annotate physical documents by placing them under the document camera and selecting "Doc Cam"
- Microphones for Online use**
 Ceiling mounted microphones capture your voice for Zoom/Teams meetings.
- Tracking Cameras**
 Cameras follow your movement by default, tracking settings can be adjusted in the camera control menu.

Troubleshooting Tips

- Can't connect to wireless sharing**
 Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- No Audio in Zoom/Teams**
 Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"
- No Sound from connected laptop**
 Set device audio output to "Crestron"
- Can't see Doc Cam in Zoom/Teams**
 Set the camera within the software to the document camera, then share your screen
- Can't access built in cameras on connected laptop**
 Use the in room computer to use the in room cameras or microphones in Zoom/Teams

 Press Shutdown → Confirm YES to power off audio/video



Scan this QR code to see more details about classroom features and resources

