



Classroom Touch Panel

*shown in Presentation Mode

1. Instruction Mode - Presentation - same source on all displays
 Group - group sources on all displays (see reverse for group mode instructions)
2. Blank Screens - Black out the classroom displays
3. Shutdown - Access the shut down menu to end class
4. Camera Control - Camera selection and controls
5. PC - Instructor Computer content
6. Laptop- Content from laptop/tablet
 connected with HDMI cable
7. Wireless - Wireless presentation content
8. Doc Cam - Document Camera content
9. Volume - Volume control slider

Turn on System

Select Presentation Mode from the main standby screen


Select a Source

Tap the desired source icon from the center of the interface

Adjust Volume

Press the “up” and “down” arrows to adjust the system volume
 Tap the speaker button below to mute and unmute the system

Turn off System


Tap Shutdown  icon in upper right corner of interface
 Tap “YES” when prompted to power off system

Classroom Features

- Multiple displays for student collaboration
- Instructor computer
- Document Camera
- Wireless presentation (see additional instructions)
- Computer monitor with annotation capability
- Ink2Go (screen annotation software see additional instructions)
- Camera for web conferencing

For more information, visit the GMU Stearns Center website:

<https://stearnscenter.gmu.edu>



Classroom Touch Panel

*shown in Group Mode

1. Instruction Mode - Presentation - same source on all displays (see reverse for presentation mode instructions)
Group - group sources on all displays
2. Blank Screens - Black out the classroom displays
3. Shutdown - Access the shut down menu to end class
4. Camera Control - Camera selection and controls
5. Group Icons - Choose a group to share to all displays
6. Return to Group - Return to individual group mode
7. Volume - Volume control slider

Turn on System

Select Group Mode from the main standby screen

Select a Group

Tap the desired group icon from the center of the interface

The selected group will be outlined in white

This group will be shared to all displays

Return to Group

When a group is selected, the Return to Group option is shown

Press the group icon with “Yes” underneath


to return to showing each group on their respective display

Adjust Volume

Press the “up” and “down” arrows to adjust the system volume

Tap the speaker button below to mute and unmute the system

Turn off System

Tap Shutdown  icon in upper right corner of interface

Tap “YES” when prompted to power off system

