



Start System - press anywhere on the touch panel

- | | |
|---------------------------|---|
| 1 Presentation | Mode 1: Show your selected source on all displays |
| 2 Group | Mode 2: Each student group can wirelessly connect to a display around the room. Select a group from touch-panel to mirror that group on all displays |
| 3 Blank Screens | Temporarily turn off all displays (press again to restore) |
| 4 Microphones | Mute/unmute and adjust volume for each microphone |
| 5 Computer Source | Show display from the classroom PC or from your personal laptop (use HDMI cable on lectern) |
| 6 Volume | Adjust or mute program audio |
| 7 Camera Controls | Adjust camera (tilt, pan, zoom) and enable/disable tracking |
| 8 Wireless | Present wirelessly from anywhere in the room using any tablet, mobile device, or laptop. See separate guide for detailed connection instructions |
| 9 Doc Cam | Display documents or objects for in-room or online participants |
| 10 Camera Tracking | Indicates the status of camera tracking (enabled by default) |

Classroom Features

Group mode

- Switch to group mode to send allow each group to wirelessly connect to their nearest display. Select a Group to mirror their display around the room

Wireless Sharing

- Share your device screen wirelessly from an tablet or mobile device by selecting "Wireless" on the touch panel.

Microphones for In-Room use

- Use the lapel, handheld or lectern microphone for better speech in the room

Microphones for Online use

- Ceiling mounted microphones capture your voice for Zoom/Teams meetings.

Tracking Cameras

- Cameras follow your movement by default, tracking settings can be adjusted in the camera control menu.

Software

- PC is installed with ZOOM for online conferencing and Ink2Go for lecture annotation and

Troubleshooting Tips

Can't connect to wireless sharing

- Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password

No Audio in Zoom/Teams

- Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"

No Sound from connected laptop

- Set device audio output to "Crestron"

Personal wireless mic doesn't work

- This system does not support personal mics; contact support staff for assistance

Can't see Doc Cam in Zoom/Teams

- Set the camera within the software to the document camera, then share your screen

Can't see in room cameras on connected laptop

- Use the in room computer to use the rooms cameras or microphones in Zoom/Teams

 Press Shutdown → Confirm YES to power off audio/video



Scan this QR code to see more details about classroom features and resources

