



Classroom Features

- Group mode**
Switch to group mode to send allow each group to wirelessly connect to their nearest display. Select a Group to mirror their display around the room
- Wireless Sharing**
Share your device screen wirelessly from an tablet or mobile device by selecting "Wireless" on the touch panel.
- Microphones for In-Room use**
Use the lapel, handheld or lectern microphone for better speech in the room
- Microphones for Online use**
Ceiling mounted microphones capture your voice for Zoom/Teams meetings.
- Tracking Cameras**
Cameras follow your movement by default, tracking settings can be adjusted in the camera control menu.
- Software**
PC is installed with ZOOM for online conferencing and Ink2Go for lecture annotation and

Troubleshooting Tips

- Can't connect to wireless sharing**
Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- No Audio in Zoom/Teams**
Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"
- No Sound from connected laptop**
Set device audio output to "Crestron"
- Personal wireless mic doesn't work**
This system does not support personal mics; contact support staff for assistance
- Can't see Doc Cam in Zoom/Teams**
Set the camera within the software to the document camera, then share your screen
- Can't see in room cameras on connected laptop**
Use the in room computer to use the rooms cameras or microphones in Zoom/Teams

Start System - press anywhere on the touch panel

1 Presentation

Mode 1: Show your selected source on all displays

2 Group

Mode 2: Each student group can wirelessly connect to a display around the room. Select a group from touch-panel to mirror that group on all displays

3 Blank Screens

Temporarily turn off all displays (press again to restore)

4 Microphones

Mute/unmute and adjust volume for each microphone

5 Computer Source

Show display from the classroom PC or from your personal laptop (use HDMI cable on lectern)

6 Volume

Adjust or mute program audio

7 Camera Controls

Adjust camera (tilt, pan, zoom) and enable/disable tracking

8 Wireless

Present wirelessly from anywhere in the room using any tablet, mobile device, or laptop. See separate guide for detailed connection instructions

9 Doc Cam

Display documents or objects for in-room or online participants

10 Camera Tracking

Indicates the status of camera tracking (enabled by default)



Press Shutdown



Confirm YES to power off audio/video



Scan this QR code to see more details about classroom features and resources

