



Start System - press anywhere on the touch-panel

- | | |
|---------------------------|--|
| 1 Presentation | Mode 1: Show your selected source on all displays |
| 2 Group | Mode 2: Send each groups content to the nearest display or mirror one group to all displays |
| 3 Blank Screens | Turn off all displays (press again to restore) while the PC remains on |
| 4 Microphones | Mute/unmute and adjust volume for each microphone |
| 5 Computer Source | Show display from the classroom PC or from your personal laptop (use HDMI cable on lectern) |
| 6 Volume | Adjust or mute program audio |
| 7 Camera Controls | Adjust view, zoom, pan, and enable/disable tracking |
| 8 Wireless | Flexibly present content from laptop or tablet from anywhere in the room |
| 9 Document Camera | Display documents or objects for in-room or online participants |
| 10 Camera Tracking | Indicates the status of camera tracking (enabled by default) |

Classroom Features

- **Conferencing Software**
Zoom and Microsoft Teams are installed on the rooms PC for starting and joining meetings
- **Wireless Sharing**
Share your device screen wirelessly from an iPad, phone, or computer by selecting "Wireless" on the touch panel.
- **Document Camera**
Display or annotate physical documents by placing them under the document camera.
- **Microphones for In-Room use**
Use the lapel, handheld or lectern microphone for better speech in the room
- **Microphones for Online use**
Ceiling mounted microphones capture your voice for Zoom/Teams sessions.
- **Tracking Cameras**
Cameras follow your movement automatically and can be adjusted manually from the touch panel.
- **Assisted Listening**
Support Students with hearing needs. Please see the support office for device checkout

Troubleshooting Tips

- **Can't connect to wireless sharing**
Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- **No Audio in Zoom/Teams**
Set speaker and microphone settings within the software to "AV Bridge"
- **No Sound from connected laptop**
Set Windows or Mac audio output device to "Crestron"
- **Personal wireless mic doesn't work**
This system does not support personal mics, contact support staff for assistance
- **Can't see Doc Cam in Zoom/Teams**
Set the camera within the software to the document camera then share your screen
- **Can't see in room cameras on connected laptop**
Use the in room computer to use the in room cameras or microphones in Zoom/Teams

 Press Shutdown → Confirm YES to power off audio/video

