



## Start System - press anywhere on the touch panel

- |                          |  |
|--------------------------|--|
| <b>1 Presentation</b>    | <b>Mode 1:</b> Show your selected source on all displays   |
| <b>2 Group</b>           | <b>Mode 2:</b> Show different wireless content on each display, select a group to mirror it to all displays                                      |
| <b>3 Blank Screens</b>   | Temporarily turn off all displays (press again to restore)   |
| <b>4 Microphones</b>     | Mute/unmute and adjust volume for each microphone  |
| <b>5 Computer Source</b> | Show display from the classroom PC or from your personal laptop (use HDMI cable on lectern)  |
| <b>6 Volume</b>          | Adjust or mute program audio   |
| <b>7 Camera Controls</b> | Adjust camera (tilt, pan, zoom) and save/recall preset camera positions  |
| <b>8 Wireless</b>        | Present wirelessly from anywhere in the room using any tablet, mobile device, or laptop. See separate guide for detailed connection instructions |
| <b>9 Doc Cam</b>         | Display documents or objects for in-room or online participants  |

## Classroom Features

### Software

- PC is installed with Ink2go for annotating and recording classes and ZOOM for conferencing and remote participation

### Wireless Sharing

- Share your device screen wirelessly from an tablet or mobile device by selecting "Wireless" on the touch panel.

### Microphones for In-Room use

- Use the lapel, handheld or lectern microphone for better speech in the room

### Microphones for Online use

- Ceiling mounted microphones capture your voice for Zoom/Teams meetings.

### High definition cameras

- High definition cameras can be used with conferencing software or to record classes. Adjust settings in the camera control menu.

## Troubleshooting Tips

- Can't connect to wireless sharing**  
Connect to the "eduroam" WiFi network, log in using your GMU email (i.e. netid@gmu.edu) and password
- No Audio in Zoom/Teams**  
Set speaker and microphone settings within the conferencing software to "AV Bridge" or "Crestron"
- No Sound from connected laptop**  
Set device audio output to "Crestron"
- Personal wireless mic doesn't work**  
This system does not support personal mics; contact support staff for assistance
- Can't see Doc Cam in Zoom/Teams**  
Set the camera within the software to the document camera, then share your screen
- Can't see in room cameras on connected laptop**  
Use the in room computer to use the rooms cameras or microphones in Zoom/Teams



Press Shutdown



Confirm YES to power off audio/video



Scan this QR code to see more details about classroom features and resources

